


## Change Existing 4:1 Menu

**NOTE:** Press the **"TEMP"** key for each level. Press the **"UP ARROW"** key to change the flashing number and press the **"RIGHT ARROW"** key to move to the next digit.

1. Press and hold the **"PROGRAM"** key (5 sec) or until the software version is displayed.



2. Press the **"PROGRAM"** key Twice until **"SYSTEM SETUP"** appears.




3. Press and hold the **"UP ARROW"** key (approximately 8 sec) until Gap Calibration appears. **Do Not** change the gap calibration offset



4. Press the **"PROGRAM"** key twice for **"MENU ITEMS"**.



5. Press the **"MENU SELECT"** key twice for **"4:1 Clam Yes"**.



6. Press the **"Temp"** key: **Remove In: 110 sec**




7. Press the **"TEMP"** key until **"Alarm"** is displayed. Press the **"UP ARROW"** key to toggle between Auto or Manual - select : **"AUTO"**




8. Press the **"TEMP"** key: **Gap Settings: .450**




9. Press the **"TEMP"** key: **Stage 1 Time: 20 sec.**




10. Press the **"TEMP"** key: **Stage 1 Gap: .400**




11. Press the “TEMP” key: **Stage 2 Time: 000 sec.**




12. Press the “TEMP” key: **Stage 2 Gap: .000**



13. Press the “TEMP” key: **Stage 3 Time: 000 sec.**




14. Press the “TEMP” key: **Stage 3 Gap: 000**



15. Press the “TEMP” key: **Must Remove in: 000**




16. Press the “TEMP” key: **Toast Buns 000**



17. Press the “TEMP” key until “Alarm” is displayed. Press the “UP ARROW” key to toggle between Auto or Manual - select : “AUTO”



18. Press the “TEMP” key: **TOP TEMP: 425 F**



19. Press the “TEMP” key: **BOTTOM TEMP: 350F**



20. Press the “TEMP” key multiple times to scroll through the menu to verify the changes you made are correct.

**Return To Main Menu**

1. Press the “PROGRAM” key once
2. Press the “RIGHT ARROW” key once

**THE COOK TIME IS A “START POINT” FOR COOKING. AFTER THE PROGRAMMING CHANGES ARE MADE, COMPLETE A “BEEF INTEGRITY” CHECK TO SET THE CORRECT COOK TIME FOR THE PRODUCT.**