



GARLAND GAS & ELECTRIC
CLAMSHELL GRILLS
WITH PRODUCT RECOGNITION

MWE3W, MWE3S, MWG3W



TO PROGRAM WORLD GRILL FOR ANGUS 3:1, CANADA

1. Press and hold the **P** button for approximately three, (3), seconds. "MENU ITEM 1" will be displayed.
2. Using **↔** scroll until you find "ANGUS 3:1 CLAM".
3. Press **↔**. "ANGUS 3:1 CLAM PRODUCT" will be displayed.
4. Press **↔** you will see "NO DISPLAY ACTIVE".
5. Press the **↔**. "NO" will flash.
6. Press **↑** to change "NO" to "YES".
7. Press the **↔** to accept change.
8. Press **↔** until you see "REMOVE IN TIME".
9. Press **↔**. Current time will flash.
10. Using **↓** change time to "190".
11. Press **↔** to accept change.
12. Press **↔** until you see "GAP SETTING".
13. Press **↔**. Current gap setting will flash.
14. Using **↑** change gap setting to "574".
15. Press **↔** to accept change.
16. Press **↔**. You will see "GAP MUL/PR START".
17. Press **↔**. Current number will flash.
18. Using **↑** change setting to "574".
19. Press **↔** to accept change.
20. Press the **P** button twice to return to normal operation.

**ANGUS 3:1
CANADA**