

Create the new 4:1 BEST BURGER Recipe

						Cooking Temp (F)		Stage 1 Cooking			Stage 2 Remove Time			Total Time (sec)
Product Display	Menu	Auto	Grill Surface	#Per Run	Recipe Cooking Methodology	Platen	Grill	Gap (MILS)	Time (sec)	Prompt	Gap (MILS)	Time (sec)	Prompt	
4.1 Clam	PM		Iron		Standard	425	350	400	20	None	450	90	None	110



1. Select All Recipes.




7. Select STANDARD GRILLED then, press check-mark to continue.



2. Type 1177 then press Return.


Note: Access available to store manager (1177).




3. Press CREATE NEW.




4. Type your new Recipe Name: **4:1 CLAM** then, press return.



5. Select an image then, press check, or import one.




6. Under SELECT RECIPE TYPE, Select NORMAL then, press check-mark to continue.




8. Enter the information from the table above. Stage 1 cooking.

9. Use the up & down arrow to scroll to the options.



10. Press the right arrow to create and Stage 2 Cooking.



11. Select check-mark to continue, or the X to cancel.

4:1 CLAM

↑ COOKING TIME MIN: 0 MAX: 9999	90 SECS	2 OUT OF 2 ← [Menu] →
↓ GAP MIN: 0 MAX: 2000	450 MILS	
FLAT COOKING	NO	✓
PROMPT SELECTION	NONE	
UPPER PLATEN MIN: 149 F MAX: 450 F OFF: 32F	425 F	
GRILL PLATEN MIN: 149 F MAX: 400 F OFF: 32F	350 F	
GRILL FRONT MIN: 149 F MAX: 400 F OFF: 32F	350 F	

easy TOUCH

12. Enter the information from the table above. Stage 2 cooking.
13. Use the up & down arrow to scroll to the options.
14. Select check mark to save your work.

ALL RECIPE

SAVED! ✓

CREATE NEW

easy TOUCH

15. Save - do not interrupt the process.
16. Press home icon to return to HOME screen.

ACTIVATE RECIPE CREATED (406 FRESH PATTY)

1. Select Menus.

Press & Go

MENUS ALL RECIPES

SETTINGS DIAGNOSTICS

easy TOUCH

2. Type 1177 then press Return.

Note: Access available to store manager (1177).

Password

1 2 3 4 5 6 7 8 9 0

q w e r t y u i o p

a s d f g h j k l

z x c v b n m

SPACE RETURN

easy TOUCH

3. Select the PM Menu and, then select the edit pen icon (top right corner).

MENU

Auto AM PM

Auto AM MENU PM MENU

CREATE NEW

easy TOUCH

4. Press return to continue. Do not rename the Menu.

MENU NAME

PM Menu

Limit: 15 characters

1 2 3 4 5 6 7 8 9 0

q w e r t y u i o p

a s d f g h j k l

z x c v b n m

SPACE RETURN

easy TOUCH

5. Press check mark to continue. Do not make any change on preheat settings.

MENU PREHEAT SETTINGS

UPPER PLATEN 425 F

GRILL PLATEN 365 F

GRILL FRONT 365 F

FLAT FRONT NO

easy TOUCH

6. Press check mark to continue. Do not change the default image.

PM MENU

M3 M2 4:1 M2

Auto PM Round Eggs PM

easy TOUCH

7. Select the recipe created 4:1 CLAM then press the check mark to continue.

PM MENU

Onions 4:1 Sausage Round Eggs

Steak Auto AM PM

easy TOUCH

8. Select the order of the new recipe then Press the check mark to continue. By default the new recipe will be at the bottom of the list.

PM MENU

1 RECIPE NUMBER ONE

2 RECIPE NUMBER TWO

3 RECIPE NUMBER THREE

easy TOUCH

9. Saved - do not interrupt the process.

PM MENU

1 RECIPE NUMBER ONE

2 RECIPE

3 RECIPE

SAVED! ✓

easy TOUCH

10. Press home icon to return to HOME screen.

HOME SCREEN

Press & Go

MENUS ALL RECIPES

SETTINGS DIAGNOSTICS

easy TOUCH