




## **4:1 BEST BURGER PROGRAMMING INSTRUCTIONS** **"CHANGING EXISTING 4:1 PROGRAM"**

**For use with Garland models: MWE3W, MWG3W, MWE3W-1, MWG3W-1, MWE2W, MWG2W, MWE1W, MWG1W, MWE2W-1, MWG2W-1, MWE1W-1, MWG1W-1**

The following procedures will be used for all 1, 2 and 3 Platen Garland "Product Recognition" GAS & ELECTRIC Clam Grills cooking. These procedures should be followed in sequence.

### **Overview**


- 1- **Enter Programming Mode:** Enter McDonald's AM/PM Menu program mode.
- 2- **Change Settings for Menu Items:** These steps show how to change Grill Set Point / Remove In Time / Gap Setting and Multi Stage Settings.
























### **Detail Procedures**

#### **1- Enter Programming Mode To Change Existing 4:1 Settings**





- 1.1 Press ◀ or ▶ button until **"4:1 – CLAM"** is displayed.
- 1.2 Press and Hold the **P** button for approximately three (3) seconds. Controller will display **"4:1 – CLAM"** and corresponding item number.




- 1.3 Press the  button. Controller will display **"PRODUCT"**.
- 1.4 Press  button until **"GRILL SETPT"** is displayed.
- 1.5 Press the  button. The Current setting will begin to flash.
- 1.6 Using the  or  button, change the current setting to **350**
- 1.7 Press the  button to save the new setting.
- 1.8 Press the  button until **"INSTANT ON TIME"** is displayed.
- 1.9 Press the  button. The Current setting will begin to flash.
- 1.10 Using the  or  button, change the current setting to **0 sec.**
- 1.11 Press the  button to save the new setting.
- 1.12 Press the  button until **"REMOVE IN TIME"** is displayed.
- 1.13 Press the  button. The Current setting will begin to flash.
- 1.14 Using the  or  button, change the current setting to **110 sec** start time.

- 1.15 Press the  button to save the new setting.
- 1.16 Press the  button until **"MULTI STAGE 1 TIME"** is displayed
- 1.17 Press the  button. The Current setting will begin to flash.
- 1.18 Using the  or  button, change the current setting to **20 sec.**
- 1.19 Press the  button to save the new setting.

**NOTE:** "MULTI STAGE 2 & 3 TIMES" are set at **0 sec.**

- 1.20 Press the  button until **"GAP SETTING"** is displayed.
- 1.21 Press the  button. The current setting will begin to flash.
- 1.22 Using the  or  button change the current setting to **450**



1.23 Press the ➡ button until **"GAP MULTI/PR START"** is displayed.

1.24 Press the ⬅ button. The Current setting will begin to flash.

1.25 Using the ⬆ or ⬇ button, change the current setting to **400**

1.26 Press the ⬅ button to save the new setting.

1.27 Press the ➡ button until **"GAP MULTI STAGE 1"** is displayed.

1.28 Press the ⬅ button. The Current setting will begin to flash.

1.29 Using the ⬆ or ⬇ button, change the current setting to **450**

1.30 Press the ⬅ button to save the new setting.

**NOTE:** "GAP MULTI STAGE 2 & 3" are set at **0**

1.31 Press the ➡ button multiple times to **"SCROLL"** through all menu settings to verify that all your changes are correct.

1.32 Press the **P** button **TWICE** to exit and return to the normal operating mode.

***THE COOK TIME IS A "START POINT" FOR COOKING. AFTER THE PROGRAMMING CHANGES ARE MADE, COMPLETE A "BEEF INTEGRITY" CHECK TO SET THE CORRECT COOK TIME FOR THE PRODUCT.***

041417JED